

### Principal changes to FUELSTAT® test kits

- We now recommend that a 1 Litre fuel sample is taken, agitated using a swirling motion and left to settle for 12-15 mins before starting the FUELSTAT® test
- All water or fuel phase samples should be extracted from near the bottom of the 1L sample using the syringe and extraction tube now supplied in each kit
- An alcohol wipe and updated instructions are included in the kit to help minimise the risk of cross contamination



NEW SYRINGE & EXTRACTION TUBE

UPDATED INSTRUCTIONS

NEW ALCOHOL WIPE



### What advantages do these updates mean for users of FUELSTAT®?

- **Repeatability and reliability** of testing are improved with new kit contents and clear updated instructions
- **More accuracy and consistency of results** from outlying locations, regardless of operator experience and working conditions
- **Easier to use** with enhanced kit contents and a simple process for water phase or fuel phase test samples

### Extra cost?

- No. **Free of charge**, included in the kit.

### PRODUCT SUPPORT

Comprehensive support information on the website: [www.conidia.com](http://www.conidia.com)

Multiple language PDF and video instructions are available for all users in Spanish (European & Latin American), French, German, Portuguese (Brazilian), Russian, Chinese (Simplified & Traditional), Indian (Hindi & Punjabi)

- PDF: [www.conidia.com/resources/fuelstat-literature/#instructions](http://www.conidia.com/resources/fuelstat-literature/#instructions)
- Video: [www.conidia.com/resources/fuelstat-videos/](http://www.conidia.com/resources/fuelstat-videos/)

Conidia Bioscience Ltd  
Bakeham Lane, Egham,  
Surrey, TW20 9TY, UK  
+44 (0)1491 829102  
[info@conidia.com](mailto:info@conidia.com)

Conidia  
Bioscience  
[WWW.CONIDIA.COM](http://WWW.CONIDIA.COM)

Conidia Bioscience Inc  
15 Briarwood Ln, Dover,  
NH, 03820, USA  
+1 407 616 0315  
[info@conidia.com](mailto:info@conidia.com)